

AUDI V25.80

MODEL	SYSTEM	TYPE	System Info.	Read-Clear Dtc	Data stream	Actuation	Specail functions
100	03 Brake Electronics	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	15 Airbags	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	02 Transmission ElectronicsI	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	35 Central Locking	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	08 AC/Heating electronics	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	38 ROOF ELECTRONICS	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	01 Engine electronics	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	25 Immobilizer	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
200	03 Brake Electronics	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	15 Airbags	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	02 Transmission ElectronicsI	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	35 Central Locking	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	08 AC/Heating electronics	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	38 ROOF ELECTRONICS	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	01 Engine electronics	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	25 Immobilizer	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
80	03 Brake Electronics	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	15 Airbags	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	02 Transmission ElectronicsI	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	35 Central Locking	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	08 AC/Heating electronics	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	38 ROOF ELECTRONICS	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	01 Engine electronics	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	25 Immobilizer	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
90	03 Brake Electronics	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	15 Airbags	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	02 Transmission ElectronicsI	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	35 Central Locking	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	08 AC/Heating electronics	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	38 ROOF ELECTRONICS	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	01 Engine electronics	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>

A2	25 Immobilizer	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	03 Brake Electronics	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	03 Brake Electronics	(01-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	15 Airbags	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	49 Auto. Lighting switch	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	02 Transmission ElectronicsI	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	35 Central Locking	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	19 Gateway data bus	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	08 AC/Heating electronics	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	46 Central Control Module	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	38 ROOF ELECTRONICS	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	17 Instrument Cluster	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	16 16 Steering Wheel Electronics Electronics	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	75 Emergency call module	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	01 Engine electronics	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	25 Immobilizer	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	29 Left light control	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	37 Navigation	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	39 Right light control	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
47 Soundsystem	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>	
56 Radio	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>	
A3	03 Brake Electronics	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	03 Brake Electronics	(01-02)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	03 Brake Electronics	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	15 Airbags	(..-01)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	15 Airbags	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	25 Immobilizer	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	49 Auto. Lighting switch	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	7D Auxiliary Heater	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	7D Auxiliary Heater	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	71 Battery charger	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	61 Battery control	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	43 BRAKER BOOST.ASSI.	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>

09 Electronic Ctrl Electronics	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
19 Gateway data bus	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
08 AC/Heating electronics	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
08 AC/Heating electronics	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
12 Clutch electronics	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
46 Central Control Module	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
46 Central Control Module	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
38 ROOF ELECTRONICS	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
38 ROOF ELECTRONICS	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
13 Distance control	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
17 Instrument Cluster	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
17 Instrument Cluster	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
DRIVER FOOT BOAR	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
DRIVER SEAT CONTR	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
42 DRIVER-DOOR ELECT.	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
42 DRIVER-DOOR ELECT.	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
09 Electronic Ctrl Electronics	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
16 16 Steering Wheel Electronics Electronics	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
16 16 Steering Wheel Electronics Electronics	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
75 Emergency call module	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
01 Engine electronics	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
01 Engine electronics 1.8T AQA	(99-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
01 Engine electronics 1.9 TDI BKC	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
01 Engine electronics 2.0 TDI BKD	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
01 Engine electronics	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
01 Engine electronics	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
07 DISPLAY-/CNTL UNIT	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
55 Headlight range control	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
25 Immobilizer	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
25 Immobilizer	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
62 LR-DOOR ELECTRONI.	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
62 LR-DOOR ELECTRONI.	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
29 Left light control	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>

	53 Parking Brake	(..00)	info	err.code	data	actuat.	spec.
	76 Parking aid	(..00)	info	err.code	data	actuat.	spec.
	52 PASSE-DOOR ELECT.	(..00)	info	err.code	data	actuat.	spec.
	52 PASSE-DOOR ELECT.	(03-..)	info	err.code	data	actuat.	spec.
	PASS.FOOT BOARD	(..00)	info	err.code	data	actuat.	spec.
	PASSIVE ENTRY	(..00)	info	err.code	data	actuat.	spec.
	23 BRAKER BOOSTER	(..00)	info	err.code	data	actuat.	spec.
	56 Radio	(03-..)	info	err.code	data	actuat.	spec.
	27 DIS./CTL UNIT REAR	(..00)	info	err.code	data	actuat.	spec.
	39 Right light control	(..00)	info	err.code	data	actuat.	spec.
	72 RR-DOOR ELECTRONI.	(..00)	info	err.code	data	actuat.	spec.
	72 RR-DOOR ELECTRONI.	(03-..)	info	err.code	data	actuat.	spec.
	SEAT/MIRROR POS.	(..00)	info	err.code	data	actuat.	spec.
	16 Steering Wheel Electronics	(..00)	info	err.code	data	actuat.	spec.
	16 Steering Wheel Electronics	(03-..)	info	err.code	data	actuat.	spec.
	14 Wheel damping electronics	(..00)	info	err.code	data	actuat.	spec.
	65 Tyre pressure monitoring	(..00)	info	err.code	data	actuat.	spec.
	24 Drive slip control	(..00)	info	err.code	data	actuat.	spec.
	TRANSPORT MODALI	(03-..)	info	err.code	data	actuat.	spec.
	57 TV-TUNER	(..00)	info	err.code	data	actuat.	spec.
	67 VOICE CONTROL	(..00)	info	err.code	data	actuat.	spec.
A4	22 4WD Electronics	(..03)	info	err.code	data	actuat.	spec.
	03 Brake Electronics	(..03)	info	err.code	data	actuat.	spec.
	03 Brake Electronics	(01-..)	info	err.code	data	actuat.	spec.
	03 Brake Electronics	(04-..)	info	err.code	data	actuat.	spec.
	15 Airbags	(..01)	info	err.code	data	actuat.	spec.
	15 Airbags	(01-04)	info	err.code	data	actuat.	spec.
	15 Airbags	(04-..)	info	err.code	data	actuat.	spec.
	25 Immobilizer	(..00)	info	err.code	data	actuat.	spec.
	25 Immobilizer	(04-..)	info	err.code	data	actuat.	spec.
	49 Auto. Lighting switch	(..00)	info	err.code	data	actuat.	spec.
	02 Transmission Electronicsl	(..03)	info	err.code	data	actuat.	spec.
	7D Auxiliary Heater	(..00)	info	err.code	data	actuat.	spec.

7D Auxiliary Heater	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
71 Battery charger	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
61 Battery control	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
43 BRAKER BOOST.ASSI.	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
09 Electronic Ctrl Electronics	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
35 Central Locking	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
19 Gateway data bus	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
08 AC/Heating electronics	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
08 AC/Heating electronics	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
08 AC/Heating electronics	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
12 Clutch electronics	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
COLUMN/SEAT REG.	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
46 Central Control Module	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
46 Central Control Module	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
38 ROOF ELECTRONICS	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
38 ROOF ELECTRONICS	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
13 Distance control	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
17 Instrument Cluster	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
17 Instrument Cluster	(01-04)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
17 Instrument Cluster	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
DIGITAL RADIO TUNE	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
DRIVER FOOT BOAR	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
DRIVER SEAT CONTR	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
42 DRIVER-DOOR ELECT.	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
42 DRIVER-DOOR ELECT.	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
09 Electronic Ctrl Electronics	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
16 16 Steering Wheel Electronics Electronics	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
16 16 Steering Wheel Electronics Electronics	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
75 Emergency call module	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
EMERGENCY MODUL	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
01 Engine electronics	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
01 Engine electronics 1.9 TDI AWX	(01-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
01 Engine electronics	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>

01 Engine electronics	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
07 DISPLAY-/CNTL UNIT	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
55 Headlight range control	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
55 Headlight range control	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
25 Immobilizer	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
25 Immobilizer	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
62 LR-DOOR ELECTRONI.	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
62 LR-DOOR ELECTRONI.	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
29 Left light control	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
53 Parking Brake	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
76 Parking aid	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
52 PASSE-DOOR ELECT.	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
52 PASSE-DOOR ELECT.	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
PASS.FOOT BOARD	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
PASSIVE ENTRY	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
PHONE	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
23 BRAKER BOOSTER	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
56 Radio	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
56 Radio	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
27 DIS./CTL UNIT REAR	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
39 Right light control	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
72 RR-DOOR ELECTRONI.	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
72 RR-DOOR ELECTRONI.	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
SEAT/MIRROR POS.	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
16 Steering Wheel Electronics	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
16 Steering Wheel Electronics	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
14 Wheel damping electronics	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
56 Radio	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
65 Tyre pressure monitoring	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
24 Drive slip control	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
57 TV-TUNER	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
57 TV-TUNER	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
67 VOICE CONTROL	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>

A6(..00)	25 Immobilizer	(..00)	info	err.code	data	actuat.	spec.
	49 Auto. Lighting switch	(..00)	info	err.code	data	actuat.	spec.
	7D Auxiliary Heater	(..00)	info	err.code	data	actuat.	spec.
	71 Battery charger	(..00)	info	err.code	data	actuat.	spec.
	61 Battery control	(..00)	info	err.code	data	actuat.	spec.
	43 BRAKER BOOST.ASSI.	(..00)	info	err.code	data	actuat.	spec.
	12 Clutch electronics	(..00)	info	err.code	data	actuat.	spec.
	38 ROOF ELECTRONICS	(..00)	info	err.code	data	actuat.	spec.
	13 Distance control	(..00)	info	err.code	data	actuat.	spec.
	17 Instrument Cluster	(..00)	info	err.code	data	actuat.	spec.
	DRIVER FOOT BOAR	(..00)	info	err.code	data	actuat.	spec.
	DRIVER SEAT CONTR	(..00)	info	err.code	data	actuat.	spec.
	42 DRIVER-DOOR ELECT.	(..00)	info	err.code	data	actuat.	spec.
	09 Electronic Ctrl Electronics	(..00)	info	err.code	data	actuat.	spec.
	75 Emergency call module	(..00)	info	err.code	data	actuat.	spec.
	01 Engine electronics 2.8 V6 5v AQD	(00-..)	info	err.code	data	actuat.	spec.
	01 Engine electronics	(..00)	info	err.code	data	actuat.	spec.
	07 DISPLAY-/CNTL UNIT	(..00)	info	err.code	data	actuat.	spec.
	25 Immobilizer	(..00)	info	err.code	data	actuat.	spec.
	62 LR-DOOR ELECTRONI.	(..00)	info	err.code	data	actuat.	spec.
	29 Left light control	(..00)	info	err.code	data	actuat.	spec.
	53 Parking Brake	(..00)	info	err.code	data	actuat.	spec.
	76 Parking aid	(..00)	info	err.code	data	actuat.	spec.
	52 PASSE-DOOR ELECT.	(..00)	info	err.code	data	actuat.	spec.
	PASS.FOOT BOARD	(..00)	info	err.code	data	actuat.	spec.
	PASSIVE ENTRY	(..00)	info	err.code	data	actuat.	spec.
	23 BRAKER BOOSTER	(..00)	info	err.code	data	actuat.	spec.
	27 DIS./CTL UNIT REAR	(..00)	info	err.code	data	actuat.	spec.
	39 Right light control	(..00)	info	err.code	data	actuat.	spec.
	72 RR-DOOR ELECTRONI.	(..00)	info	err.code	data	actuat.	spec.
	SEAT/MIRROR POS.	(..00)	info	err.code	data	actuat.	spec.
	47 Soundsystem	(..00)	info	err.code	data	actuat.	spec.
16 Steering Wheel Electronics	(..00)	info	err.code	data	actuat.	spec.	

	14 Wheel damping electronics	(..00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	56 Radio	(..00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	65 Tyre pressure monitoring	(..00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	24 Drive slip control	(..00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	57 TV-TUNER	(..00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	67 VOICE CONTROL	(..00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
A6(..03)	22 4WD Electronics	(..03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	03 Brake Electronics	(..03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	15 Airbags	(..03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	02 Transmission ElectronicsI	(..03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	35 Central Locking	(..03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	19 Gateway data bus	(..03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	08 AC/Heating electronics	(..03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	46 Central Control Module	(..03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	16 16 Steering Wheel Electronics Electronics	(..03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	01 Engine electronics	(..03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	55 Headlight range control	(..03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	56 Radio	(..03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
A6(04-..)	02 Transmission ElectronicsI	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	61 Battery control	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	CHANGE BRAKE PAD	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	CHASSIS MANAGEME	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	COLUMN/SEAT REG.	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	13 Distance control	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	DIGITAL RADIO TUNE	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	DIGITAL TV TUNER	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	DISTANCE REGULATI	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	EMERGENCY MODUL	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	01 Engine electronics	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	HATCHBACK DOOR E	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	IDENT./COMMAND UN	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	IND./COMMAND UNIT	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	MEDIA PLAYER POSI	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>

	37 Navigation	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	53 Parking Brake	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	76 Parking aid	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	PHONE	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	REAR SEAT REG.	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	ROOF MANAGEMENT	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	SPECIAL FUNCTION	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	14 Wheel damping electronics	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	65 Tyre pressure monitoring	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
A6	ELECT. CENTRAL SY	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	MEDIA PLAYER POSI	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	PASSENGER SEAT R	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	RELEV/SWITCON	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	SAT. RADIO TUNER	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	47 Soundsystem	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	SUPP HEATER/AUTO	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	67 VOICE CONTROL	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
A8(..-00)	49 Auto. Lighting switch	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	71 Battery charger	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	61 Battery control	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	43 BRAKER BOOST.ASSI.	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	DRIVER FOOT BOAR	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	42 DRIVER-DOOR ELECT.	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	09 Electronic Ctrl Electronics	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	75 Emergency call module	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	01 Engine electronics	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	01 Engine electronics	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	07 DISPLAY-/CNTL UNIT	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	62 LR-DOOR ELECTRONI.	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	29 Left light control	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	53 Parking Brake	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	52 PASSE-DOOR ELECT.	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	PASS.FOOT BOARD	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>

	PASSIVE ENTRY	(..00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	23 BRAKER BOOSTER	(..00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	27 DIS./CTL UNIT REAR	(..00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	39 Right light control	(..00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	72 RR-DOOR ELECTRONI.	(..00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	47 Soundsystem	(..00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	56 Radio	(..00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	65 Tyre pressure monitoring	(..00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	57 TV-TUNER	(..00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	67 VOICE CONTROL	(..00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
A8(..03)	22 4WD Electronics	(..03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	19 Gateway data bus	(..03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	16 16 Steering Wheel Electronics Electronics	(..03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
A8(..99)	03 Brake Electronics	(..99)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	15 Airbags	(..99)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	02 Transmission Electronicsl	(..99)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	35 Central Locking	(..99)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	08 AC/Heating electronics	(..99)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	38 ROOF ELECTRONICS	(..99)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	17 Instrument Cluster	(..99)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	01 Engine electronics	(..99)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	25 Immobilizer	(..99)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
A8(04-..)	22 4WD Electronics	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	03 Brake Electronics	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	15 Airbags	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	02 Transmission Electronicsl	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	7D Auxiliary Heater	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	61 Battery control	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	09 Electronic Ctrl Electronics	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	CHANGE BRAKE PAD	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	CHASSIS MANAGEME	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	08 AC/Heating electronics	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	COLUMN/SEAT REG.	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>

46 Central Control Module	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
38 ROOF ELECTRONICS	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
13 Distance control	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
17 Instrument Cluster	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
DIGITAL RADIO TUNE	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
DIGITAL TV TUNER	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
DISTANCE REGULATI	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
DRIVER IDENT.	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
42 DRIVER-DOOR ELECT.	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
16 16 Steering Wheel Electronics Electronics	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
EMERGENCY MODUL	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
01 Engine electronics	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
HATCHBACK DOOR E	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
55 Headlight range control	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
IDENT./COMMAND UN	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
25 Immobilizer	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
IND./COMMAND UNIT	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
LANE CHANGE ASSY	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
LANE MANT. ASSYST.	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
62 LR-DOOR ELECTRONI.	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
MEDIA PLAYER POSI	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
37 Navigation	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
53 Parking Brake	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
76 Parking aid	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
52 PASSE.-DOOR ELECT.	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
PHONE	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
56 Radio	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
REAR 08 AC/Heating electronics	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
REAR SEAT REG.	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
72 RR-DOOR ELECTRONI.	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
ROOF MANAGEMENT	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
SPECIAL FUNCTION	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
16 Steering Wheel Electronics	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>

	14 Wheel damping electronics	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	65 Tyre pressure monitoring	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	57 TV-TUNER	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	VEICHL POSITION R	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
A8	ELECT. CENTRAL SY	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	MEDIA PLAYER POSI	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	PASSENGER SEAT R	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	RELEV/SWITCON	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	SAT. RADIO TUNER	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	47 Soundsystem	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	SUPP HEATER/AUTO	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	67 VOICE CONTROL	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
Cabrio	03 Brake Electronics	(..-99)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	15 Airbags	(..-99)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	02 Transmission ElectronicsI	(..-99)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	71 Battery charger	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	61 Battery control	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	43 BRAKER BOOST.ASSI.	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	35 Central Locking	(..-99)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	08 AC/Heating electronics	(..-99)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	38 ROOF ELECTRONICS	(..-99)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	17 Instrument Cluster	(..-99)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	DRIVER FOOT BOAR	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	42 DRIVER-DOOR ELECT.	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	09 Electronic Ctrl Electronics	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	75 Emergency call module	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	01 Engine electronics	(..-99)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	01 Engine electronics	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	07 DISPLAY-/CNTL UNIT	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	25 Immobilizer	(..-99)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	29 Left light control	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	37 Navigation	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	53 Parking Brake	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>

	52 PASSE-DOOR ELECT.	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	PASS.FOOT BOARD	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	PASSIVE ENTRY	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	23 BRAKER BOOSTER	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	27 DIS./CTL UNIT REAR	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	39 Right light control	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	47 Soundsystem	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	56 Radio	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	57 TV-TUNER	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	67 VOICE CONTROL	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
Coupe'	03 Brake Electronics	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	15 Airbags	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	02 Transmission ElectronicsI	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	71 Battery charger	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	61 Battery control	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	43 BRAKER BOOST.ASSI.	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	35 Central Locking	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	08 AC/Heating electronics	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	38 ROOF ELECTRONICS	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	17 Instrument Cluster	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	DRIVER FOOT BOAR	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	42 DRIVER-DOOR ELECT.	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	09 Electronic Ctrl Electronics	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	75 Emergency call module	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	01 Engine electronics	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	01 Engine electronics	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	07 DISPLAY-/CNTL UNIT	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	25 Immobilizer	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	29 Left light control	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	37 Navigation	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	53 Parking Brake	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	52 PASSE-DOOR ELECT.	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	PASS.FOOT BOARD	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>

	PASSIVE ENTRY	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	23 BRAKER BOOSTER	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	27 DIS./CTL UNIT REAR	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	39 Right light control	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	47 Soundsystem	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	56 Radio	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	57 TV-TUNER	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	67 VOICE CONTROL	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
S6	03 Brake Electronics	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	15 Airbags	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	02 Transmission ElectronicsI	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	71 Battery charger	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	61 Battery control	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	43 BRAKER BOOST.ASSI.	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	35 Central Locking	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	08 AC/Heating electronics	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	38 ROOF ELECTRONICS	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	17 Instrument Cluster	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	DRIVER FOOT BOAR	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	42 DRIVER-DOOR ELECT.	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	09 Electronic Ctrl Electronics	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	75 Emergency call module	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	01 Engine electronics	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	01 Engine electronics	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	01 Engine electronics	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	07 DISPLAY-/CNTL UNIT	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	25 Immobilizer	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	29 Left light control	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	37 Navigation	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	53 Parking Brake	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	52 PASSE-DOOR ELECT.	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	PASS.FOOT BOARD	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	PASSIVE ENTRY	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>

	23 BRAKER BOOSTER	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	27 DIS./CTL UNIT REAR	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	39 Right light control	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	47 Soundsystem	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	56 Radio	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	57 TV-TUNER	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	67 VOICE CONTROL	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
S8	03 Brake Electronics	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	15 Airbags	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	02 Transmission ElectronicsI	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	35 Central Locking	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	08 AC/Heating electronics	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	38 ROOF ELECTRONICS	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	17 Instrument Cluster	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	01 Engine electronics	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	01 Engine electronics	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	01 Engine electronics	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	25 Immobilizer	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
TT	03 Brake Electronics	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	15 Airbags	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	02 Transmission ElectronicsI	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	35 Central Locking	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	19 Gateway data bus	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	08 AC/Heating electronics	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	38 ROOF ELECTRONICS	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	17 Instrument Cluster	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	16 16 Steering Wheel Electronics Electronics	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	01 Engine electronics	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	01 Engine electronics	(01-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	25 Immobilizer	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
V8	22 4WD Electronics	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	03 Brake Electronics	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	03 Brake Electronics	(01-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>

15 Airbags	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
49 Auto. Lighting switch	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
02 Transmission Electronicsl	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
71 Battery charger	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
61 Battery control	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
43 BRAKER BOOST.ASSI.	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
35 Central Locking	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
08 AC/Heating electronics	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
38 ROOF ELECTRONICS	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
17 Instrument Cluster	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
DRIVER FOOT BOAR	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
42 DRIVER-DOOR ELECT.	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
09 Electronic Ctrl Electronics	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
75 Emergency call module	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
01 Engine electronics	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
01 Engine electronics	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
07 DISPLAY-/CNTL UNIT	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
25 Immobilizer	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
62 LR-DOOR ELECTRONI.	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
29 Left light control	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
53 Parking Brake	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
52 PASSE.-DOOR ELECT.	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
PASS.FOOT BOARD	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
PASSIVE ENTRY	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
23 BRAKER BOOSTER	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
27 DIS./CTL UNIT REAR	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
39 Right light control	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
72 RR-DOOR ELECTRONI.	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
47 Soundsystem	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
56 Radio	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
65 Tyre pressure monitoring	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
57 TV-TUNER	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
67 VOICE CONTROL	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>

before 2007	01 Engine electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	11 Engine electronics 2	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	21 Engine electronics 3	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	02 Transmission Electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	03 Brake Electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	08 AC/Heating electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	25 Immobilizer	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	47 Soundsystem	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	12 Clutch electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	34 Self leveling suspension	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	15 Airbags	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	16 Steering Wheel Electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	44 Steering assistance	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	35 Central Locking	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	14 Wheel damping electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	17 Instrument Cluster	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	18 Aux heating	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	13 Distance control	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	19 Gateway data bus	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	26 Electric roof control	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	29 Left light control	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	39 Right light control	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	37 Navigation	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	45 Interior Monitoring	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	46 Central Control Module	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	49 Auto. Lighting switch	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	51 Electric drive	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	61 Battery control	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	75 Emergency call module	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
	76 Parking aid	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
09 Electronic Ctrl Electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>	
22 4WD Electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>	
24 Drive slip control	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>	

36 Driver`s side seat adj.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
41 Diesel pump electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
55 Headlight range control	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
56 Radio	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
65 Type pressure monitoring	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
66 Seat-/mirror adjust.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
71 Battery charger	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
42 DRIVER-DOOR ELECT.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
52 PASSE.-DOOR ELECT.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
62 LR-DOOR ELECTRONI.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
72 RR-DOOR ELECTRONI.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
23 BRAKER BOOSTER	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
43 BRAKER BOOST.ASSI.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
63 DRVS BOARDING ASS1	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
73 DRVS BOARDING ASS2	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
54 Rear spoiler	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
05 ACCESS & PERMISSI.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
06 PASSENE. SEAT ADJ.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
07 DISPLAY-/CNTL UNIT	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
27 DIS./CTL UNIT REAR	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
57 TV-TUNER	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
67 VOICE CONTROL	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
77 TELEPHONE	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
38 ROOF ELECTRONICS	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
48 DRVS SEAT ADJ.REAR	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
68 WIPER ELECTRONICS	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
78 SLIDING DOOR	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
59 TOWING PROTECTION	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
69 TRAILER FUNCTION	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
28 Climate Control Unit Rear	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
31 Engine Electronics Conjunct.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
32 Locking Electronic	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
53 Parking Brake	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>

58 Auxiliary Fuel Tank	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
64 Stabilizers	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
1C Vehicle Position Detection	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
2D Voice Amplification	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
3D Special Function	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
6E Roof Display/Control Head	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
7E Ind.Unit in Inst.Panel Ins.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
0D Sliding Door Left	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
7D Auxiliary Heater	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
0F Radio Tuner-Digital	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
1F Radio Satellite	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
2F TV TunerDigital	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
04 Steering Position	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
74 Vehicle Control System	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
3C Lane Departure Assistance System	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
4C Tyre Pressure Monitor II	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
5C Lane Keeping Assistance System	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
6C Rear Camera	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
5D Opertion	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
6D Electronic Equipment of Trunk Lid	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
0B Auxiliary Air Heater	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
5F Information Electronic Equipment 1	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
6F Confort Central Control Unit II	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
1B Power-Assisted Steering	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
10 Parking Assist System 2	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
7F Left Slide Door	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
01 Engine electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
11 Engine electronics 2	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
21 Engine electronics 3	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
02 Transmission Electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
03 Brake Electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
08 AC/Heating electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
25 Immobilizer	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>

47 Soundsystem	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
12 Clutch electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
34 Self leveling suspension	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
15 Airbags	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
16 Steering Wheel Electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
44 Steering assistance	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
35 Central Locking	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
14 Wheel damping electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
17 Instrument Cluster	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
18 Aux heating	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
13 Distance control	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
19 Gateway data bus	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
26 Electric roof control	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
29 Left light control	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
39 Right light control	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
37 Navigation	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
45 Interior Monitoring	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
46 Central Control Module	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
49 Auto. Lighting switch	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
51 Electric drive	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
61 Battery control	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
75 Emergency call module	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
76 Parking aid	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
09 Electronic Ctrl Electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
22 4WD Electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
24 Drive slip control	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
36 Driver`s side seat adj.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
41 Diesel pump electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
55 Headlight range control	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
56 Radio	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
65 Type pressure monitoring	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
66 Seat-/mirror adjust.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
71 Battery charger	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>

42 DRIVER-DOOR ELECT.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
52 PASSE.-DOOR ELECT.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
62 LR-DOOR ELECTRONI.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
72 RR-DOOR ELECTRONI.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
23 BRAKER BOOSTER	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
43 BRAKER BOOST.ASSI.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
63 DRVS BOARDING ASS1	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
73 DRVS BOARDING ASS2	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
54 Rear spoiler	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
05 ACCESS & PERMISSI.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
06 PASSENE. SEAT ADJ.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
07 DISPLAY-/CNTL UNIT	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
27 DIS./CTL UNIT REAR	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
57 TV-TUNER	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
67 VOICE CONTROL	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
77 TELEPHONE	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
38 ROOF ELECTRONICS	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
48 DRVS SEAT ADJ.REAR	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
68 WIPER ELECTRONICS	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
78 SLIDING DOOR	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
59 TOWING PROTECTION	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
69 TRAILER FUNCTION	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
28 Climate Control Unit Rear	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
31 Engine Electronics Conjunct.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
32 Locking Electronisc	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
53 Parking Brake	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
58 Auxiliary Fuel Tank	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
64 Stabilizers	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
1C Vehicle Position Detection	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
2D Voice Amplification	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
3D Special Function	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
6E Roof Display/Control Head	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
7E Ind.Unit in Inst.Panel Ins.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>

0D Sliding Door Left	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
7D Auxiliary Heater	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
0F Radio Tuner-Digital	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
1F Radio Satellite	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
2F TV Tuner-Digital	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
04 Steering Position	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
74 Vehicle Control System	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
3C Lane Departure Assistance System	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
4C Tyre Pressure Monitor II	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
5C Lane Keeping Assistance System	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
6C Rear Camera	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
5D Opertion	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
6D Electronic Equipment of Trunk Lid	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
0B Auxiliary Air Heater	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
5F Information Electronic Equipment 1	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
6F Confort Central Control Unit II	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
1B Power-Assisted Steering	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
10 Parking Assist System 2	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
7F Left Slide Door	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
01 Engine electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
11 Engine electronics 2	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
44 Steering assistance	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
05 ACCESS & PERMISSI.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
21 Engine electronics 3	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
31 Engine Electronics Conjunct.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
61 Battery control	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
02 Transmission Electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
22 4WD Electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
42 DRIVER-DOOR ELECT.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
52 PASSE.-DOOR ELECT.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
62 LR-DOOR ELECTRONI.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
62 RR-DOOR ELECTRONI.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
03 Brake Electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>

13 Distance control	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
53 Parking Brake	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
34 Self leveling suspension	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
15 Airbags	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
25 Immobilizer	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
55 Headlight range control	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
65 Tyre pressure monitoring	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
75 Emergency call module	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
06 PASSENE. SEAT ADJ.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
16 Steering Wheel Electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
26 Electric roof control	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
36 Driver`s side seat adj.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
46 Central Control Module	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
56 Radio	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
66 Seat-/mirror adjust.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
76 Parking aid	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
1D Driver identification	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
3D Special Function	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
07 DISPLAY-/CNTL UNIT	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
17 Instrument Cluster	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
37 Navigation	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
47 Soundsystem	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
57 TV-TUNER	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
67 VOICE CONTROL	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
77 TELEPHONE	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
0E Media player position 1	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
1E Media player position 2	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
2E Media player position 3	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
3E Media player position 4	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
4E Control head RR	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
5E Control head LR	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
7E Ind.Unit in Inst.Panel Ins.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
08 AC/Heating electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>

18 Aux heating	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
28 Climate Control Unit Rear	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
38 ROOF ELECTRONICS	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
7D Auxiliary Heater	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
09 Electronic Ctrl Electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
19 Gateway data bus	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
69 TRAILER FUNCTION	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
0F Radio Tuner-Digital	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
1F Radio Satellite	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
2F TV Tuner-Digital	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
4F Electronic central electric II	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
04 Steering Position	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
74 Vehicle Control System	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
3C Lane Departure Assistance System	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
4C Tyre Pressure Monitor II	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
5C Lane Keeping Assistance System	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
6C Rear Camera	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
5D Opertion	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
6D Electronic Equipment of Trunk Lid	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
0B Auxiliary Air Heater	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
5F Information Electronic Equipment 1	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
6F Confort Central Control Unit II	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
1B Power-Assisted Steering	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
10 Parking Assist System 2	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
20 High Beam Assistance Device	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
30 Special Function 2	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>
7F Left Slide Door	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	<i>spec.</i>